



# Desktop PC RAM Replacement

This guide will show the steps to properly remove and replace the RAM in a desktop computer.

Written By: David Lennon



## INTRODUCTION

RAM(Random Access Memory) is a very fast type of memory. It stores short term information so that it can be accessed quickly. Replacing RAM in a computer can help a computer run more quickly and smoothly.


---



### TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

## Step 1 — Left Panel



**⚠** Unplug the computer from the power supply before any maintenance or disassembly.

- Remove the two Phillips #2 head 5mm screws from the back side of the computer case. You only need to remove the screws that hold down the panel.

**i** These screws can be removed by hand.

## Step 2




- Next, remove the side panel of the computer case to allow access into the computer. Slide the panel towards the back of the computer and lift it up to remove.

**⚠** If there is a fan mounted on the side panel, make sure to unplug the cable before fully removing the panel.



## Step 3 — RAM



- Unlock the RAM by unclipping the white tabs from either side of the RAM.

## Step 4



- Remove the RAM sticks from the computer casing.
- ⓘ Repeat the above step and this step as necessary. Some computers could have many sticks of RAM.

To reassemble your device, follow these instructions in reverse order.

- When replacing the RAM, place the replacement into the RAM slot and lock the white tabs in.

